



## **Wellseal Tool Running Procedure**

***\*\*Prior to running the Wellseal tool it is imperative that the well be circulated and conditioned well, as debris has been known to damage the tool during cementing.***

### **Tool Installation**

- It is recommended that you install the tool one joint above the surface casing shoe.
- The tool will slide over the casing with the metal ring portion of the tool facing downwards.
- Once tool is at desired portion of casing, fasten set screws.
- Install a rigid centralizer above the tool.

### **Cementing**

- Run cement job at operational speed.
- Cement will flow through the tool during the cementing process.
- Once cement has flown through the tool, the weight of the cement will automatically engage check valve flap on top of the tool.
- It is recommended that you hold pressure on the tool until cement is finished setting up.
- job done.

*Note: The tool can also be used to swab cement to surface where required.*

Questions or Concerns? Please contact Cam Mitchell – 24 hour availability – (403) 801-8624